\square

For more information view the user manual online at

www.junipersys.com/emberequine/support

PN 27245-01









CHARGE THE 4VETJ INTERNAL BATTERY USING THE AC POWER SUPPLY FOR 4-6 HOURS 2 TURN THE UNIT ON AND WAIT FOR THE SYSTEM TO LOAD