## **Attach the Carry Handle**

The Mesa Pro carry handle attaches to the top edge of the tablet with two screws.

To attach the Mesa Pro carry handle.

- 1. Place the handle on the top edge of the tablet, catching the lip of the handle over the front edge of the tablet.
- 2. Press the back of the handle firmly against the tablet and align the right screw hole.



3. Position a screw straight into the hole and tighten lightly.



4. Press the back of the handle firmly against the tablet and align the left screw hole.

5. Position a screw straight into the hole and tighten lightly.



6. Completely tighten the right screw. Completely tighten the left screw.



CAUTION: The carry handle is designed to fit snugly against the tablet. Do not modify the handle for a looser fit.

## **Attach the Carry Handle**

The Mesa Pro carry handle attaches to the top edge of the tablet with two screws

To attach the Mesa Pro carry handle.

- 1. Place the handle on the top edge of the tablet, catching the lip of the handle over the front edge of the tablet.
- 2. Press the back of the handle firmly against the tablet and align the right screw hole.



3. Position a screw straight into the hole and tighten lightly.



4. Press the back of the handle firmly against the tablet and align the left screw hole.

5. Position a screw straight into the hole and tighten lightly.



6. Completely tighten the right screw. Completely tighten the left screw.



CAUTION: The carry handle is designed to fit snugly against the tablet. Do not modify the handle for a looser fit.

Copyright Feb 2023, Juniper Systems, Inc. All rights reserved. Information is subject to change without notice. Part Number 31660-01.

Copyright Feb 2023, Juniper Systems, Inc. All rights reserved. Information is subject to change without notice. Part Number 31660-01.